ROBO KIDS 1 Parts List			
Part Picture	Part Name / Code	Quantity	
0	Tire - Ø50 (PW1N-N002)	2	
	Wheel - Ø50 (PW0N-N001)	1	
	Double Sided Tape (PA1S-N002)	4	
\bigcirc	Cable 450mm (PL0M-N002)	3	
\frown	Cable 200mm (PL0M-N001)	7	
	1 x 10 Hole Block (PB0H-N004)	2	
	1 x 12 Block (PB0N-N005)	2	
	1 x 2 Block (PB0N-N001)	4	
50	1 x 2 Hole Block (PB0H-N001)	2	
	1 x 4 Block (PB0N-N002)	4	
3000	1 x 4 Hole Block (PB0H-N002)	4	
A S S S S S S	1 x 6 Block (PB0N-N003)	2	

000000	1 x 6 Hole Block (PB0H-N003)	2
B B B B B B B B B B B B B B B B B B B	1 x 8 Block (PB0N-N004)	4
	2 x 2 Block (PB0N-N006)	12
and and sold	2 x 3 Block (PB0N-N007)	5
C.C.C.C.	2 x 4 Block (PB0N-N008)	15
	2 x 6 Block (PB0N-N009)	10
	2 x 8 Block (PB0N-N010)	5
	CPU Block (PC0M-N009)	1
	DC Motor - 100 RPM (PM0D-N008)	2
	LED Block [Red] (PC1D-N007)	1
	LED Block [Blue] (PC1D-N010)	1
	Buzzer Sensor (PC1D-N011)	1
0	IR Sensor (PC0S-N004)	1

	Contact Sensor (PC0S-N005)	3
225	2 x 4 Flat Block (PB0F-N002)	1
	Main Block (PB0F-N001)	2
	Wheel Block (PB0H-N007)	2
	Wheel Axle (PB0S-N005)	2
	Connection Axle (PB0S-N001)	5
	Funny Card Pack 1 (PV0K-N010)	1
	Robo Kids Workbook 1 [ENG] (PV0K-N013-140)	1
	Support Block (PB0S-N009)	1
	Card Reader (PC1R-N001)	1
	Wheel - Ø50 (PW0K-N002)	2